



# Thermal Capture Cross Section determination of $^{241}\text{Am}$ using the FRM-II Cold Neutron Beam

Christoph Genreith<sup>1</sup>, Matthias Rossbach<sup>1</sup>

<sup>1</sup> Institute of Energy and Climate Research, IEK-6, Forschungszentrum Jülich GmbH, 52425 Jülich, Germany




## Neutron Capture Data of Minor Actinides are inconsistent




- Safe containment for actinides
- Transparency for neutrons
- Transparency for photons
- Avoid elements that change the neutron beams temperature
- As few elements as possible to reduce interference






*Preparation of  $^{241}\text{Am}$  nitrate sample. A  $12\mu\text{l}$  droplet of solution is dried on the surface of a thin gold foil.*




*Radiographic image of most massive  $^{237}\text{NpO}_2$  and gold sample.*

**Samples can be regarded as thin!**






Samples are placed at an angle of  $45^\circ$  with the neutron beam in the sample chamber in front of the detector.




Detector

Opening of  
Samplechamber




$^{241}\text{Am}$   
Sample

Teflon<sup>®</sup>  
Sampleholder




**Resonance region is avoided with the cold neutron beams**

# Thermal Capture Cross Section of $^{241}\text{Am}$



Thermal cross sections calculated using the  $^{242}\text{Pu}$  X-Ray emission at 99 and 103 keV after  $^{242}\text{gAm}$  decay to  $^{242}\text{Pu}$






- Correct peak areas for the
- absorption in the Quartz;
- Calculate neutron flux with decay measurement of gold foil.

Correction via Lambert-Beer law:


$$\frac{P_c}{P_m} = \kappa_{abs} = e^{\mu_{Al}(E_\gamma)x}$$




## Effect

Absorption in glass	1,4%
Neutronshielding gold	0.2%


# Why $^{242}\text{Pu}$ x-rays?



# Thermal Capture Cross Section of $^{241}\text{Am}$



**Thermal cross sections calculated to  $725.4 \pm 34.4$  b and  $711.1 \pm 28.2$  b**








## Conclusion:

- Thermal capture cross sections have been calculated.

## Outlook:

- How could the differences to other measurements be explained?





**We want to thank for the great assistance at the instrumental facilities. In particular to:**

## **Budapest PGAA group:**


- Tamás Belgya
- Laszlo Szentmiklose

## **Munich PGAA group:**



- Zsolt Reváy
- Petra Kudjejova

## **Forschungszentrum Jülich:**


- Dr. Giuseppe Modolo
- Ralf König



Thank you for your attention!







- | Correct peak areas for the
- | attenuation in the quartz.
- |  $^{241}\text{Am}$  side of the sample was
- | turned to the detector for
- | Measurement.

1

Correction factor:

$$\kappa_{sc}(E_\gamma) = \frac{P_r}{P_c}$$

Real peakarea  
without self-  
attenuation

Peakarea with  
self-attenuation

Energy [keV]	$\kappa_{sc}$
49.47	1.27
182.84	1.05
5352.03	1.00