


The Stability of Uranium Microspheres for Future Application as Reference Standards

Ronald Middendorp, Martin Dürr

ESARDA 38th annual meeting, DA WG meeting
26 May 2016, Luxembourg





Particle production with vibrating orifice aerosol generator:

- 1) Liquid feed with known isotopic composition
- 2) Generation of monodisperse aerosol ($m_U = Q/f \cdot c_U$)
- 3) Drying & thermal treatment; conversion of uranium to UO_x
- 4) Particle collection by inertial impaction

Introduction

Particle preparation



Introduction

Particle preparation options


Currently: direct collection on substrates

Particle suspensions offer many advantages:

- e.g. particle mixtures, homogeneity, etc...

But, stability might be an issue

- e.g. dissolution, isotope exchange, etc...





Production

Processing


Characterization

Distribution


TGA/SEM



Uranyl nitrate
 $T = 500$ °C









Uranyl chloride
 $T = 500$ °C



Uranyl acetate
 $T = 400$ °C

Precursor solution

SEM/FIB



Uranyl nitrate
 $T = 500\text{ }^{\circ}\text{C}$

Uranyl chloride
 $T = 500\text{ }^{\circ}\text{C}$

Uranyl acetate
 $T = 400\text{ }^{\circ}\text{C}$


Precursor solution

Particle characterization

X-ray diffraction, X-ray near-edge absorption spectroscopy and raman spectroscopy to determine structure

XRD


microXAS beamline (PSI)
4x1.5 μm beam (17.2 keV)



Orthorhombic U_3O_8 phase

XANES


microXAS beamline (PSI)
300x300 μm beam (U L_3 edge)



$\text{U}^{\text{V}}/\text{U}^{\text{VI}}$ mixture (U_3O_8)


Raman

μ -raman spectroscopy (CEA)
0.6 μm laser (514 nm)



Uranyl chloride comparable

Particles (still deposited on Si wafers) have been stored in solvents:




Images are collections of various micrographs taken under similar conditions

Particle detachment

Particles have been removed from substrate by ultrasonification

- Successful for ethanol and 2-propanol, but not for n-hexane

Particle detachment depends (mostly) on density and viscosity^[1]:




^[1] Awad S, Nagarajan R. Ultrasonic cleaning. In: Kohli R, Mittal KL, editors. Developments in Surface Contamination and Cleaning. 2010. p.225-280.

Introduction

Exchange between traces of ^{nat}U in matrix and particles

Two reaction mechanisms^[1]:

- Surface exchange ← major role
- Diffusion




Experiments performed between $[\text{LEU}]\text{UO}_2^{2+}$ (aq) and $[\text{DU}]\text{UO}_x$ (s)

- Q-ICP-MS measurement of liquid phase

^[1] Cole DR, Chakraborty S. Rates and Mechanisms of Isotopic Exchange. *Rev Mineral Geochem* 2001;**43**:83-140.

Uranium isotope exchange

Results



Uranium isotope exchange




Results

Exchange rate UO_3 faster than U_3O_8

➤ Exchange via U(VI)

Faster exchange at higher pH

➤ Likely due to hydroxide formation^[1]



^[1] Szabó and Grenthe, *Inorg. Chem.*, **46**, 9372 (2007).

Particle production and characterization

Microparticles have been produced successfully

- Particles have been produced from IRMM-183 and IRMM-023

Optimization of production, production using:

- Uranyl nitrate ➤ Suitable; porous
- Uranyl chloride ➤ No advantages to uranyl nitrate
- Uranyl acetate ➤ Suitable; dense

Characterization with XRD, XANES and raman spectroscopy

- Uranyl nitrate ➤ U_3O_8 (even at 400 °C)
- Uranyl acetate ➤ U_3O_8
- Uranyl chloride ➤ only raman, similar to nitrate and acetate

Dissolution studied in various solvents:

- Solvent penetrates dense shell and reaches pores
- No dissolution in ethanol, 2-propanol (104 d) and n-decane (16 d)

Isotope exchange measured in aqueous solutions

- Significant exchange rates measured at neutral pH
- Exchange via U(VI) hydroxides
- For U_3O_8 : $T_{1/2} = 60.9(47) \text{ d}$

Supported by:



Federal Ministry
of Economics
and Technology

on the basis of a decision
by the German Bundestag



PTKA
Projektträger Karlsruhe
im Karlsruher Institut für Technologie

Thank you for your kind attention!

Ronald Middendorp

Forschungszentrum Jülich GmbH
Institute for Energy and Climate Research
IEK-6: Nuclear Waste Management and Reactor Safety
D-52428 Jülich, Germany

Tel.: +49 2461 61-4884

E-mail: r.middendorp@fz-juelich.de