


# In operando NMR investigations of electrolyte chemistry during CO<sub>2</sub> electrolysis

ICCDU | 26th June 2023 I S. Jovanovic, P. Jakes, S. Merz, R.-A. Eichel, J. Granwehr



#### **Motivation**




**Local pH** and **electrolyte chemistry** play a critical role for CO<sub>2</sub> electrolysis!

- Local pH
   affects catalytic pathways
- CO<sub>2</sub>/HCO<sub>3</sub> equilibrium
   affects CO<sub>2</sub> resupply
- Cation chemistry
   affects product selectivity



#### **Motivation**



**Local pH** and **electrolyte chemistry** play a critical role for CO<sub>2</sub> electrolysis!

Investigation of local electrolysis phenomena requires in operando methods!




#### Overview In Operando NMR spectroscopy

- Benefits
- 1. Wide toolset of experiments to investigate system interactions
- 2. Straightforward assessment of chemical species
- 3. Selective studies of molecular properties

- Challenges
- 1. Magnetic field distorationby conductive cell components
- 2. Amplification of external RF noise by cables & wires
- 3. Compatibility between equipment


#### In operando Electrolysis Setup





#### Experimental In operando Experimental Procedure

Increasingly negative potential Increasing reaction rate



Open Circuit Voltage U≈ -0.04 V Underpotential U = -1.10 V Electrolysis Conditions U≈ -1.4 V

Ag Working Electrode

1M K/NaH<sup>13</sup>CO<sub>3</sub>(aq)


Electrolyte

Saturated with <sup>13</sup>CO<sub>2</sub>

- 1. <sup>13</sup>C/<sup>23</sup>Na Spectra recording for 12 hours (10 min resolution)
- **2.**  $T_1$  &  $T_2$  Relaxation Experiments
- 3. Exchange Experiment (CO<sub>2</sub>/HCO<sub>3</sub><sup>-</sup>)




#### Observation #1 13C Signal Evolution




<sup>13</sup>C spectrum of CO<sub>2</sub> saturated electrolyte



#### Observation #1 13C Signal Evolution









**OCV** 

### Observation #1 13C Signal Evolution






CO<sub>2</sub> signal only decreases in intensity, shape stays constant




OCV

# Observation #1 13C Signal Evolution




CO<sub>2</sub> signal only decreases in intensity, shape stays constant




HCO<sub>3</sub><sup>-</sup> signal splits during underpotential and electrolysis stage



Observation #1 13C Signal Evolution











Observation #1 13C Signal Evolution




Artifact distortion of main magnetic field B<sub>0</sub>




Frequency [ppm]











#### Observation #2 Magnetic field dependent effects






#### Observation #2 Magnetic field dependent effects







#### Observation #3 $T_1$ relaxation constants






#### Observation #3 $T_1$ relaxation constants







#### Observation #3 $T_1$ relaxation constants





High mobility HCO<sub>3</sub><sup>-</sup>



**Medium mobility HCO<sub>3</sub>**<sup>-</sup>



Low mobility HCO<sub>3</sub><sup>-</sup>



# Discussion HCO<sub>3</sub><sup>-</sup> Environments

#### Na<sup>+</sup>/HCO<sub>3</sub><sup>-</sup> must be...


- 1. in two chemical environments
- 2. that are exchanging in solution
- 3. and exhibit different mobilites



# Discussion HCO<sub>3</sub><sup>-</sup> Environments

#### Na<sup>+</sup>/HCO<sub>3</sub><sup>-</sup> must be...

- 1. in two chemical environments
- 2. that are exchanging in solution
- 3. and exhibit different mobilites






#### **Conclusion Potential Dependent Electrolyte Chemistry**


OCV **0.04 v** 


Underpot. –1.1 V

Electrolysis –1.4 V




Exchange rate between IP and FI decreases with increasingly negative potential







#### Conclusion Potential Dependent Electrolyte Chemistry



Exchange rate between IP and FI decreases with increasingly negative potential

Life time of IPs affects  $CO_2$  resupply by catalyzing the  $HCO_3^-$  dehydration



# IEK-9: Fundamental Electrochemistry



Prof. Rüdiger-A. Eichel Head of Institute



Prof. Josef Granwehr Head of Department



Michael Schatz
PhD Candidate





